

Applicable Age: 3 years and above

Important Warnings:

- * Follow the instructions carefully.
- * Regularly inspect the product's casing, charging components, etc. Discontinue use if any damage is found.
- * Do not disassemble or replace parts (e.g., batteries) yourself.
- * Clean only with a dry cloth.
- * Users are responsible for ensuring safe operation. The manufacturer and distributor are not liable for harm or property damage caused by misuse.
- * Retain this manual for future reference.

Charging Instructions

Power On/Off:

Slide the power switch on the back of the robot's head to the "On" position. The screen will light up with a sound prompt.

Charging:

Turn off the robot before charging. Connect the charger to the charging port. The screen will display a charging indicator.

If charged while powered on, the robot enters standby mode and cannot operate.

Lithium Battery Precautions:

- * Uses a built-in 14500 lithium battery (non-removable).
- * Avoid overcharging; do not leave unattended while charging. Stop immediately if overheating occurs.
- * Do not charge near flammable materials.
- * Keep away from water, fire, microwaves, or high-pressure containers.
- * Clean only with a dry cloth; avoid alcohol or solvents.
- * Regularly check the charger, cable, and port for damage.
- * Dispose of according to local e-waste regulations.

Key Functions

1. AI Conversation :

* Supports conversations, storytelling, nursery rhymes, language learning, weather updates, and more.

2. Voice-Controlled Movement:


* Responds to commands like "move forward," "turn left," "dance," etc.

3. Character Customization:

* Personalize the robot's name, voice, and personality via the backend settings.

Wi-Fi Setup Tutorial

1. Power on the robot, then press and hold the top button for 3 seconds to enter pairing mode.
2. Enable Bluetooth and Location services on your phone.
3. Go to your phone's Wi-Fi settings, select a network named "INFUNITY-XXX," and connect. The phone will redirect to a configuration page. If not, manually enter: <http://192.168.4.1/>.



4. Select your 2.4GHz Wi-Fi network (iPhone users: enable "Max Compatibility" for hotspots), enter the password, and click "Connect." A "Device will restart in 3s" message indicates success. The robot will announce completion.


Backend Binding

After successful network connection, the robot needs to be added to the management backend for binding to enable normal use of AI chat functionality. The complete binding steps are as follows:


1. Wake the robot with "Hi Joy" to hear a 6-digit verification code.
2. Scan the QR code or visit: <https://xiazhi.me/>.



3. Click "Console", register an account, create a new agent, and enter the verification code to bind the robot.



Console / Agents



Add Device

* Verification Code:

Cancel

Confirm

4. After binding, all AI features become available.

AI Chat Guidelines

1. Use “Hi Joy” to wake the robot. Wait for it to finish speaking before responding.
2. Press the head button to interrupt or restart a conversation.
3. Give movement commands like “Advance for 3 seconds, then turn right.”
4. Request stories, poems, or songs (copyrighted content may be restricted).
5. Designed for children aged 3–10; inappropriate topics are blocked.
6. Typical response time: under 1 second. Restart if the robot freezes.

Support and Contact

For updates, visit the official website or contact us:



INFUNITY Official Web

